



Recommended Spares List

S/N	PART NUMBER	PART DESCRIPTION (CONSUMABLES)	450 HRS	900 HRS	1350 HRS	1800 HRS	2250 HRS	QTY/UNIT
1	A063P557	KIT,FULL SERVICE	X	X	X	X	X	1

RECOMMENDED SERVICE PARTS LIST

	PART NUMBER	PART DESCRIPTION	QTY PER GENERATOR SET	CLASSIFICATION*
2	A060L761	GASKET,AIR FILTER	1	A
3	A057B750	PUMP,INJECTION	1	A
4	A047N921	PUMP,FUEL	1	A
5	A030Y328	FILTER,AIR	1	A
6	A063N529	KIT,FUEL FILTER	1	A
7	A063N523	KIT,SERVICE (w/o Engine Oil)	1	A
8	A063E055	GASKET	2	A
9	A063E037	GASKET	1	A
10	A063D063	PLUG,SPARK	1	A
11	A061Y865	GASKET,CRANKCASE	1	A
12	A063D836	DIPSTICK	1	A
13	A063D837	GASKET,CRANKCASE	1	A

	PART NUMBER	PART DESCRIPTION	QTY PER GENERATOR SET	CLASSIFICATION*
14	A041J068	SENSOR,TEMPERATURE	1	B
15	A059L176	TACHOMETER	1	B
16	A057Y741	GENERATOR	1	B
17	A042W826	GROMMET,RUBBER	1	B
18	A059W499	COIL,IGNITION	1	B
19	0508-0071	GROMMET-RUBBER	1	B
20	A057S185	BODY,THROTTLE (ASSY)	1	B
21	A057B734	INJECTOR,FUEL	1	B
22	A057Y720	SENSOR,PRESSURE	1	B
23	A057L063	SENSOR,PRESSURE	1	B
24	A059P929	GROMMET,RUBBER	1	B
25	A064G208	INVERTER (pre-programmed)	1	B
26	0308-1038	SWITCH-ROCKER	1	B
27	0320-2434-04	CIRCUIT BREAKER	1	B
28	A042W129	BLOCK,TERMINAL	1	B
29	0337-3467	STRAP-BOND	1	B
30	A057M313	COVER, ENCLOSURE ASSEMBLY	1	B
31	A059V464	DOOR,ENCLOSURE	1	B
32	0823-0015	SCREW-TORX SHLDR (THD FORM)	4	B
33	A041J068	SENSOR,TEMPERATURE	1	B
34	A063D855	GASKET	1	B
35	A063E127	MOTOR,STARTER (Gasoline)	1	B
36	A063V498	MOTOR,STARTER (LP)	1	B
37	A061Y859	PLUG,DRAIN	1	B
38	A063D068	SENSOR,LEVEL	1	B
39	A061R805	SPACER	1	B
40	A062G654	INSERT	1	B
41	A062T791	FITTING,HOSE CONNECTOR (EVAP)	1	B
42	A062T924	HOSE,FUEL (ASSY)	1	B
43	A062T805	TUBE,FUEL (ASSY)	1	B

	PART NUMBER	PART DESCRIPTION	QTY PER GENERATOR SET	CLASSIFICATION*
44	A057K555	ENGINE,SPARK IGNITED	1	C
45	A060K886	PIPE,BREATHER	1	C
46	A061Y877	BASE,D RIP PAN	1	C
47	A061Y879	ISOLATOR	2	C
48	A035R160	SCREW,FAILSAFE	2	C
49	A061Y881	ISOLATOR	1	C
50	0517-0138-08	PLUG-HOLE	1	C
51	A057X583	PANEL,AIR BAFFLE	1	C
52	A057U198	COVER	1	C
53	A058A101	FAN	1	C
54	A058A099	BACKPLATE,FAN	1	C
55	A064B719	PANEL, DIVIDER (Hot/cold wall)	1	C
56	A057B741	ADAPTER,FUEL LINE (STRAIGHT)	1	C
57	A060H973	HOSE,FUEL (ASSY)	1	C
58	A064P029	BRACKET,FUEL PUMP	1	C
59	A060G731	TUBE,FUEL (Gasoline)	1	C
60	A060G729	TUBE,FUEL (LP)	1	C
61	A062T805	TUBE,FUEL (EVAP)	1	C
62	A060C837	BRACKET,FUEL PUMP	1	C
63	A060U210	ADAPTER,SENSOR	1	C
64	A060W101	HOUSING,AIR FILTER	1	C
65	A057K772	SILENCER,EXHAUST	1	C
66	A060N185	SUPPORT,MUFFLER	1	C



Recommended Spares List

67	A058P546	HARNES,ENGINE (Gasoline)	1	C
68	A060D237	BRACKET,SWITCH	1	C
69	A059V462	INSULATION,COVER	1	C
70	A063B884	SEAL,OIL	1	C
71	A063D835	SEAL,OIL	1	C
72	A063E057	BRACKET,ENGINE MOUNTING	1	C
73	A063E058	BRACKET,ENGINE MOUNTING	1	C
74	A063E059	BRACKET,ENGINE MOUNTING	1	C
75	A063E034	HEAD,CYLINDER	1	C
76	A063E056	SPACER	1	C
77	A063E126	KIT,VALVE	1	C
78	A063C686	FILTER,BREATHER	1	C
79	A063E129	PISTON (KIT)	1	C
80	A063E132	KIT,VALVE	2	C
81	A063E136	COVER,ASSEMBLY	1	C
82	A063E138	ARM,ROCKER (KIT)	2	C
83	A062H143	BRACKET,HEAT SHIELD	1	C
84	A062G994	PANEL,DUCT	1	C
85	A062A951	BRACKET,REGULATOR (LP)	1	C
86	A062K626	GASKET	2	C
87	A062K624	GASKET	1	C
88	A060U567	EDGING	1	C
89	A063G693	EDGING	1	C
90	A059W504	HARNES, ENGINE (LP)	1	C
91	0148-1158	SCREEN,AIR FILTER (LP)	1	C
92	A060J298	REGULATOR,FUEL (LP)	1	C
93	A034W123	SOLENOID,FUEL (LP)	1	C
94	A057X303	MIXER (LP)	1	C
95	A062T791	FITTING,HOSE CONNECTOR (EVAP)	1	C
96	A062T924	HOSE,FUEL (EVAP)	1	C
97	A062T793	VALVE,CHECK (EVAP)	1	C

*Classification:

A - Recommended Stock at Dealer Level and Distributor Level

B - Recommended Stock at Distributor Level

C - Recommended Stock at Parts Distribution Center Level

**RPN (Risk Priority Number) - Calculated based on eight service criteria. A higher RPN represents a higher stocking recommendation.

Disclaimer

Please note that this Recommended Spares List represents service parts generally used for this product. It is recommended that the generator set serial number for this product be used in conjunction with this list to assure accuracy.



Recommended Spares List

U.S. and CANADA

Cummins Inc.
 1400 73rd Avenue NE

 Minneapolis, MN 55432
 USA
 Toll Free 1-800-CUMMINS™
 (1-800-286-6467)
 Phone +1 763-574-5000
 Fax +1 763-574-5298

BRAZIL

Rua Jati, 310, Cumbica
 Guarathos, SP07180-900
 CNPJ: 43.2201.151/0001-10
 Brazil
 Phone 0800 286 6467

LATIN AMERICA

3350 Southwest 148th Ave.
 Suite 205
 Miramar, FL 33027
 USA
 Phone +1 954 431 551
 Fax +1 954 433 5797

EMEA, CIS

Cummins Inc.
 Columbus Avenue

 Manston Park
 Manston, Ramsgate
 Kent CT12 5BF
 United Kingdom
 Phone +44 1843 255000
 Fax +44 1843 255902

CHINA

Cummins Inc.
 No. 118 South Quanli Road,
 Wuhan Economic & Technological
 Development Zone, Hubei
 P.R.China 430058
 Phone + 86 (27) 8421 4008
 Fax + 86 (27) 8421 4804

MEXICO

Eje 122 No. 200 Zona Industrial
 San Luis Potosi, S.L.P 78395
 Mexico
 Phone +52 444 870 6700
 Fax +52 444 824 0082

EMEA, CIS

Cummins Inc.
 Royal Oak Way South

 Daventry
 Northamptonshire
 N11 8NU
 United Kingdom
 Phone +44 1327 88-6453
 Fax +44 1327 88-6125

INDIA

Cummins Inc.
 Plot No B-2, SEZ Industrial Area
 Village-Nandal & Surwadi,
 Taluka-Phaltan
 Dist- Satara, Maharashtra 415523
 India
 Phone +91 021 66305514

ASIA PACIFIC

Cummins.Inc.
 10 Toh Guan Road #07.01
 TT International Tradepark
 Singapore 608838
 Phone +65 6417 2388
 Fax +65 6417 2399

power.cummins.com

Copyright © 2020 Cummins Inc. All rights reserved.
 Cummins, Onan, and the "C" logo are registered trademarks of Cummins Inc. and its subsidiaries.
 Other company, product, or service names may be trademarks or service marks of others.
 Specifications are subject to change without notice.

