How to Change Inverter Settings- Rangeline

Start at the Firefly touchscreen. Hold the MODEL button for 3-10 seconds. This will take you to an Options screen.



From the Options screen press Inverter Controls.



There are 3 pages of Inverter options. Choose the setting you want to change. After the change has been made press SAVE. You must SAVE after every change, you cannot change in bulk.

O ELECTRICAL	
And the And th	Settings